

# TDS METER



## Product Features

- :: Large Display Screen - Displays mode, ATC, battery level and temperature (+ plus series models).
- :: User-Replaceable Sensor - Replace the sensors yourself. Sensor element is of SS316 stainless steel.
- :: Adjustable TDS Factor - Select the appropriate TDS factor from 0.4 to 1.0 for more accurate measurements.
- :: Waterproof, Anti-roll Design - IP67 waterproof housing keeps tester good even under wet conditions. Unique anti-roll ribbed design ensures firm grip.
- :: Innovative Cup-style - Innovative sensor housing design can be used as dip-style or cup-style for holding small volume of samples. Sensor casing is made of VALOX® for superior chemical durability.

## Applications

**General:** For use in water and wastewater treatment, boiler blow-down, electroplating rinse tanks, drinking water, hydroponics, printing industry, aquaculture, aquariums, fish farms, swimming pools and spas.

## Specifications

Product Specification	Description
Range	0 to 10.00 ppt
Resolution	0.10 ppt
Accuracy	±1% Full Scale
Temperature Coefficient	2% per °C
Operating Temperature	0 to 50 °C
Special Functions	Self-diagnostic; Hold; Auto-Power Off after 8.5 minutes
Power	4 x 1.5V button cell batteries